



Installation Instructions

1. The cut out for the doorjamb measures 8 3/8" top to bottom, and 2" from interior to exterior. Center Bandit Latch vertically with the door bolts and cut out a space for it.

Router Cutting: This method will require that a template is made first. Once a template is established, use a 1/2" diameter router bit.

Saber Saw Cutting: This method can be used on the job site. Layout and cut the 2" top and bottom cuts first. Use a fine tooth saber saw blade and cut from the backside of the jamb to achieve a smooth finished cut. Next, cut the 8 3/8" side cut. This cut will be hidden by the weather strip. It does not need to fit as accurately and does not require the radius corners that you get with a router.

2. The 2" top and bottom cuts will show where Bandit Latch adjoins. The Bandit Latch needs to fit in the cut out space well without being too tight. If the fit is too tight, the adjustable strike plates will not slide easily.
3. Install Bandit latch flush with the inner edge of the jamb. To screw the backing plate to the jamb:
 - Use two 3/4 x 8 flathead screws for the two interior holes.
 - Use five 1 1/4 drywall screws on the exterior edge

For installation questions, contact Mark Sauder:
Phone: 260.413.2119
Email: Mark@riteproductsinc.com

Rite Products, Inc.
PO Box 23
13601 Roth Rd.
Grabill, IN 46741



P: 800.572.8894
F: 260.627.5852
kara@riteproductsinc.com
www.riteproductsinc.com